

FIG.1




FIG.2




FIG.3




FIG.4




FIG.5




FIG.6




FIG.7

```
int main(int argc, char argv)
{
    if(argc==2) {
        if(strcmp(argv[1], "-v")==0)
            //EXECUTE TENTATIVE LAUNCH
            if(ConnectVAS()==OK){ //PREPARE COMMUNICATION WITH VAS
                SetAplInfo(); //PROVIDING APPLICATION INFORMATION
                Close //END OF COMMUNICATION
            }
        exit(1)
    }
    }
    NORMAL LAUNCH PROCESSING
}
```

FIG.8






FIG.9

FILE COPY INSTALL SWITCH KEY SETTING LAUNCH SETTING UNINSTALL SET

PLEASE INPUT ID AND PASSWORD

ID \_\_\_\_\_

password \_\_\_\_\_

OK CANCEL

Next

210




FIG.10A




FIG.10B

FIG.11A

217

http://www.abcde.co.jp/ \_

<- ->

BACK

ALL DELETE

1	2	3	4	5	6	7	8	9	0	-
q	w	e	r	t	y	u	i	o	p	@
a	s	d	f	g	h	j	k	l	:	:
z	x	c	v	b	n	m	.	.	.	/

CANCEL

OK

218 219

FIG.11B

217

home/applications/ \_

<- ->

BACK

ALL DELETE

1	2	3	4	5	6	7	8	9	0	-
q	w	e	r	t	y	u	i	o	p	@
a	s	d	f	g	h	j	k	l	:	:
z	x	c	v	b	n	m	.	.	.	/

CANCEL

OK

218 219




FIG. 12A




FIG. 12B

FIG.13A




FIG.13B




FIG. 14A




FIG. 14B




FIG.15A




FIG.15B





FIG.16









FIG.18




FIG.19A




FIG.19B




FIG.20A

FILE COPY

INSTALL

SWITCH KEY  
SETTING

LAUNCH  
SETTING

UNINSTALL

SET

APPLICATION NAME	DESCRIPTION	Ver.
SimplePrint	SIMPLE PRINT	2.04
SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
SimpleScan	SIMPLE SCANNER	1.80
SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10

OK

Prev

CANCEL

EXIT

Next

FIG.20B

FILE COPY

INSTALL

SWITCH KEY  
SETTING

LAUNCH  
SETTING

UNINSTALL

SET

SimpleScan

SIMPLE PRINT

2.10

THE SELECTED APPLICATION IS ALREADY REGISTERED  
IF REGISTERED AGAIN, SETTING VALUES SPECIFIC  
FOR THIS APPLICATION ARE INITIALIZED.  
REGISTER AGAIN?

OK

CANCEL

SimpleCopy

SIMPLE COPY (DOUBLE SIDED SUPPORTED)

2.10

OK

CANCEL

EXIT

Next

FIG.21A




FIG.21B




FIG.22

APPLICATION NAME	DESCRIPTION	Ver.
SimplePrint	SIMPLE PRINT	2.04
SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
SimpleScanner	SIMPLE SCANNER	1.80
SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10

Navigation buttons: Prev, Next, OK, CANCEL, EXIT (214)





FIG.24A




FIG.24B






FIG.25A




FIG.25B




FIG.26A

FILE COPY	INSTALL	SWITCH KEY SETTING	LAUNCH SETTING	UNINSTALL	SET
-----------	---------	-----------------------	-------------------	-----------	-----

APPLICATION NAME	DESCRIPTION
SimplePrint	SIMPLE PRINT 2.04
SimpleScan	SIMPLE SCAN ( ADF SUPPORTED) 1.91
SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED) 3.01
SimpleScan	SIMPLE SCANNER 1.80
SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED) 2.10

237

OK

CANCEL

EXIT

Prev

Next

FIG.26B

FILE COPY	INSTALL	SWITCH KEY SETTING	LAUNCH SETTING	UNINSTALL	SET
-----------	---------	-----------------------	-------------------	-----------	-----

SimpleCopy SIMPLE COPY (DOUBLE SIDED SUPPORTED) 2.10

THE SELECTED APPLICATION IS ALREADY REGISTERED IF REGISTERED AGAIN, SETTING VALUES SPECIFIC FOR THIS APPLICATION ARE INITIALIZED. REGISTER AGAIN?

OK

CANCEL

Next

244

210

221

FIG.27A




FIG.27B




FIG.28

FILE COPY

INSTALL

SWITCH KEY  
SETTING

LAUNCH  
SETTING

UNINSTALL

SET

APPLICATION NAME	DESCRIPTION	Ver.
SimplePrint	SIMPLE PRINT	2.04
SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
SimpleScan	SIMPLE SCANNER	1.80
SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10

Prev

OK

CANCEL

Next

EXIT

214

FIG.29A




FIG.29B




FIG.30A




FIG.30B




FIG.31A




FIG.31B




FIG.32

APPLICATION NAME	DESCRIPTION	Ver.
SimplePrint	SIMPLE PRINT	2.04
SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10
FAX&Mail	FAX&MAIL SENDING	1.10

Navigation buttons: Prev, Next, OK, CANCEL, EXIT (labeled 214)







FIG.34A

FILE COPY		INSTALL		SWITCH KEY SETTING		LAUNCH SETTING		UNINSTALL		SET																															
<table border="1"> <thead> <tr> <th>Key</th> <th>APPLICATION NAME</th> <th>DESCRIPTION</th> <th>Ver.</th> <th>PRIORITY</th> </tr> </thead> <tbody> <tr> <td>Printer</td> <td>SimplePrint</td> <td>SIMPLE PRINT</td> <td>2.04</td> <td>Prev</td> </tr> <tr> <td>scanner</td> <td>SimpleScan</td> <td>SIMPLE SCAN ( ADF SUPPORTED)</td> <td>1.91</td> <td>254</td> </tr> <tr> <td>copy</td> <td>SimpleCopy</td> <td>SIMPLE COPY (COPY AGGREGATION SUPPORTED)</td> <td>3.01</td> <td></td> </tr> <tr> <td></td> <td>SimpleScan</td> <td>SIMPLE SCANNER</td> <td>1.80</td> <td></td> </tr> <tr> <td></td> <td>SimpleCopy</td> <td>SIMPLE COPY (DOUBLE SIDED SUPPORTED)</td> <td>2.10</td> <td>Next</td> </tr> </tbody> </table>												Key	APPLICATION NAME	DESCRIPTION	Ver.	PRIORITY	Printer	SimplePrint	SIMPLE PRINT	2.04	Prev	scanner	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91	254	copy	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01			SimpleScan	SIMPLE SCANNER	1.80			SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10	Next
Key	APPLICATION NAME	DESCRIPTION	Ver.	PRIORITY																																					
Printer	SimplePrint	SIMPLE PRINT	2.04	Prev																																					
scanner	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91	254																																					
copy	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01																																						
	SimpleScan	SIMPLE SCANNER	1.80																																						
	SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10	Next																																					
										OK																															
										CANCEL																															
										EXIT																															

FIG.34B

FILE COPY		INSTALL		SWITCH KEY SETTING		LAUNCH SETTING		UNINSTALL		SET																															
<table border="1"> <thead> <tr> <th>Key</th> <th>APPLICATION NAME</th> <th>DESCRIPTION</th> <th>Ver.</th> <th>PRIORITY</th> </tr> </thead> <tbody> <tr> <td>Printer</td> <td>SimplePrint</td> <td>SIMPLE PRINT</td> <td>2.04</td> <td></td> </tr> <tr> <td>scanner</td> <td>SimpleScan</td> <td>SIMPLE SCAN ( ADF SUPPORTED)</td> <td>1.91</td> <td></td> </tr> <tr> <td>copy</td> <td>SimpleCopy</td> <td>SIMPLE COPY (COPY AGGREGATION SUPPORTED)</td> <td>3.01</td> <td></td> </tr> <tr> <td></td> <td>SimpleScan</td> <td>SIMPLE SCANNER</td> <td>1.80</td> <td></td> </tr> <tr> <td></td> <td>SimpleCopy</td> <td>SIMPLE COPY (DOUBLE SIDED SUPPORTED)</td> <td>2.10</td> <td>Next</td> </tr> </tbody> </table>												Key	APPLICATION NAME	DESCRIPTION	Ver.	PRIORITY	Printer	SimplePrint	SIMPLE PRINT	2.04		scanner	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91		copy	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01			SimpleScan	SIMPLE SCANNER	1.80			SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10	Next
Key	APPLICATION NAME	DESCRIPTION	Ver.	PRIORITY																																					
Printer	SimplePrint	SIMPLE PRINT	2.04																																						
scanner	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91																																						
copy	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01																																						
	SimpleScan	SIMPLE SCANNER	1.80																																						
	SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10	Next																																					
<p>SimpleScan SIMPLE SCAN ( ADF SUPPORTED) 1.91</p> <p>A KEY IS ASSIGNED TO THIS APPLICATION.</p> <p>DO YOU WANT TO RELEASE KEY ASSIGNMENT AND CANCEL REGISTRATION?</p>										OK																															
										CANCEL																															
										EXIT																															

FIG.35A




FIG.35B




FIG.36

FILE COPY		INSTALL		SWITCH KEY SETTING		LAUNCH SETTING		UNINSTALL		SET	
Key		APPLICATION NAME		DESCRIPTION		Ver.		PRIORITY			
Printer	SimplePrint	SIMPLE PRINT				2.04				OK	
copy	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)				3.01				Prev	
copy	SimpleScan	SIMPLE SCAN				1.80				CANCEL	
	SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)				2.10					
FAX	FAX&Mail	FAX&MAIL SENDING				1.10				Next	
										EXIT	

214

FIG.37




FIG.38




FIG.39

201  
}

RESOURCE USE INFORMATION FILE

APPLICATION ID	TEXT MEMORY AREA SIZE	HEAP AREA SIZE	STACK AREA SIZE
101	3MB	1MB	10KB
102	2MB	500KB	5KB
103	4MB	200KB	3KB
.	.	.	.
.	.	.	.
.	.	.	.

FIG.40

211  
}

PROC STRUCTURE

MEMBER NAME	DESCRIPTION
p_pid	PROCESS ID
p_txtsz	TEXT MEMORY AREA SIZE
p_heapsz	HEAP AREA SIZE,
p_stacksz	STACK AREA SIZE
.	.
.	.
.	.

FIG.41

OPERATION PANEL (HISTOGRAM)






FIG.42

FILE COPY

INSTALL

SWITCH KEY SETTING

LAUNCH SETTING

UNINSTALL

SET

Key	APPLICATION NAME	DESCRIPTION	Ver.
printer2	SimplePrint	SIMPLE PRINT	2.04
scanner3	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
scanner2	SimpleScan2	SIMPLE SCANNER Ver.2.0	2.10
copy2	NewSimpleCopy	SIMPLE COPY (DOUBLE SIDED AGGREGATION SUPPORTED)	3.32

CONSUMED MEMORY [%]

100

75

50

25

0

Prev

251

Next

OK

CANCEL

EXIT

TO INITIAL  
SETTING SCREEN

FIG.43

LAUNCH SETTING TARGET APPLICATION

FILE COPY INSTALL SWITCH KEY SETTING LAUNCH SETTING UNINSTALL SET

Key	APPLICATION NAME	DESCRIPTION	Ver.
printer2	SimplePrint	SIMPLE PRINT	2.04
scanner3	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
scanner2	SimpleScan2	SIMPLE SCANNER Ver.2.0	2.10
copy2	NewSimpleCopy	SIMPLE COPY (DOUBLE SIDED AGGREGATION SUPPORTED)	3.32

CONSUMED MEMORY (%)

100 75 50 25 0

BLINKING

Prev OK CANCEL Next EXIT

FIG.44

FILE COPY	INSTALL	SWITCH KEY SETTING	LAUNCH SETTING	UNINSTALL	SET
<div> <div> <div>OK</div> <div>print</div> <div>scan</div> <div></div> <div>scan</div> <div>copy2</div> </div> <div> <div>prev</div> <div>Next</div> </div> <div> <div>OK</div> <div>CANCEL</div> <div>EXIT</div> </div> </div>					
<p>             SINCE SYSTEM MEMORY MAY BE LACKING,              NORMAL OPERATION CAN NOT BE ASSURED.              PLEASE CHANGE APPLICATION TO LAUNCH BY              REFERRING TO CONSUMED MEMORY INDICATOR           </p> <div>OK</div>					
NewSimpleCopy		SIMPLE COPY (DOUBLE SIDED SUPPORTED)		0	3.32

FIG.45

FILE COPY	INSTALL	SWITCH KEY SETTING	LAUNCH SETTING	UNINSTALL	SET
<div style="text-align: center;"> <p>SINCE SYSTEM MEMORY MAY BE LACKING, NORMAL OPERATION CAN NOT BE ASSURED.</p> <p>DO YOU PERFORM LAUNCH SETTING?</p> <p>OK      CANCEL</p> </div>					
<div style="display: flex; justify-content: space-between;"> <div> <p>copy2</p> <p>NewSimpleCopy</p> <p>SIMPLE COPY (DOUBLE SIDED SUPPORTED)</p> <p>3.32</p> <p>0</p> <p>Next</p> </div> <div> <p>Prev</p> <p>OK</p> <p>CANCEL</p> <p>EXIT</p> </div> </div>					

FIG.46




FIG.47




FIG.48

LAUNCH SET APPLICATION

FILE COPY

INSTALL

SWITCH KEY SETTING

LAUNCH SETTING

UNINSTALL

SET

Key	APPLICATION NAME	DESCRIPTION	Ver.
printer2	SimplePrint	SIMPLE PRINT	2.04
scanner3	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
scanner2	SimpleScan	SIMPLE SCANNER Ver.2.0	1.80
copy2	SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10

CONSUMED MEMORY [%]

100

75

50

25

0

Prev

252

Next

OK

CANCEL

EXIT

FIG.49

LAUNCH SET APPLICATION

FILE COPY		INSTALL		SWITCH KEY SETTING		LAUNCH SETTING		UNINSTALL		SET	
Key	APPLICATION NAME	DESCRIPTION				Ver.		CONSUMED MEMORY [%]			
printer2	SimplePrint	SIMPLE PRINT				2.04		100			
scanner3	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)				1.91		75			
	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)				3.01		50			
scanner2	SimpleScan	SIMPLE SCANNER Ver.2.0				1.80		25			
copy2	SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)				2.10		0			
								Prev		OK	
										CANCEL	
										EXIT	
								Next			



FIG.50




FIG.51




FIG. 52

LAUNCH SETTING COMPLETED

OK

FILE COPY INSTALL SWITCH KEY SETTING LAUNCH SETTING UNINSTALL SET

copy2 SimpleCopy SIMPLE COPY (DOUBLE SIDED SUPPORTED) 0 Next

prev OK CANCEL EXIT

FIG.53

LAUNCH SET APPLICATION

FILE COPY

INSTALL

SWITCH KEY SETTING

LAUNCH SETTING

UNINSTALL

SET

Key	APPLICATION NAME	DESCRIPTION	Ver.
printer2	SimplePrint	SIMPLE PRINT	2.04
scanner3	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
scanner2	SimpleScan	SIMPLE SCANNER Ver.2.0	1.80
copy2	SimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)	2.10

CONSUMED MEMORY [%]

1007550250

Prev

OK

CANCEL

Next

EXIT

TO INITIAL  
SETTING SCREEN

FIG.54




FIG.55




FIG.56




FIG. 57






FIG.58




FIG.59




FIG.60

APPLICATION ID	INCOMPATIBLE APPLICATION ID
101	105,103
102	104
103	101
104	102
105	101

FIG.61

APPLICATION ID	ATTRIBUTE	OPERATION TARGET	APPLICATION NAME	VERSION
101	PRINTER TYPE	PRINTER	SP PRINT	1.1
102	AUTHENTICATION TYPE	OPERATION PANEL	VERIFICATION AP	2.0
103	BILLING TYPE	BILLING COUNTER	COUNT PLUS	1.01
104	AUTHENTICATION TYPE	OPERATION PANEL	AUTHENTICATION AP	1.5
105	PRINTER TYPE	PRINTER	SP PRINT	1.2
⋮	⋮	⋮	⋮	⋮

FIG.62




FIG.63




FIG.64




FIG.65






FIG.66




FIG.67




FIG.68

INDISPENSABLE APPLICATION INFORMATION FILE

APPLICATION ID	PRESENCE OR ABSENCE OF INDISPENSABLE APPLICATION	TYPE OF APPLICATION	CORRESPONDING APPLICATION ID
101	x	COPY	—
102	x	PRINTER	—
103	O	BROWSER	105
104	x	FAX	—
105	O	PLUG-IN	103
⋮	⋮	⋮	⋮
⋮	⋮	⋮	⋮

FIG.69

OPERATION PANEL

[LAUNCH REQUESTED APPLICATION]	[PRESENCE OR ABSENCE OF INDISPENSABLE APPLICATION]	[INDISPENSABLE APPLICATION]	[PRESENCE OR ABSENCE OF LAUNCH]
1.BROWSER	O	PLUG-IN	x
2.PRINTER	x	—	O
<p>&lt;LAUNCH ERROR MESSAGE&gt;</p> <p>PLEASE LAUNCH BOTH OF BROWSER AND PLUG-IN</p>			

FIG.70




FIG.71




FIG.72




FIG.73







FIG.74

PRODUCT ID	APPLICATION OF INCOMPATIBLE OR INDISPENSABLE RELATIONSHIP
101	105(-3),103(+1)
102	101(-3)
103	101(+1)
104	105(-2),106(+2)
⋮	⋮

FIG.75



# FIG.76

LAUNCH SET APPLICATION

FILE COPY

INSTALL

SWITCH KEY SETTING

LAUNCH SETTING

UNINSTALL

SET

Key	APPLICATION NAME	DESCRIPTION	Ver.
printer2	ImageBinder	SIMPLE PRINT	1.15
scanner3	SimpleScan	SIMPLE SCAN ( ADF SUPPORTED)	1.91
	SimpleCopy	SIMPLE COPY (COPY AGGREGATION SUPPORTED)	3.01
scanner2	SimpleScan2	SIMPLE SCANNER Ver.2.0	2.10
copy2	New SimpleCopy	SIMPLE COPY (DOUBLE SIDED AGGREGATION SUPPORTED)	3.32

CONSUMED MEMORY [%]

100

75

50

25

0

Prev

OK

CANCEL

EXIT

Next

TO INITIAL  
SETTING SCREEN

FIG.77




FIG.78

FILE COPY INSTALL SWITCH KEY SETTING LAUNCH SETTING UNINSTALL SET

K print scan copy2

FOR USE SELECTED APPLICATION,  
SimpleScan2 SIMPLE SCANNER Ver.2.0 2.10

NEEDS TO BE LAUNCHED.  
DO YOU PERFORM LAUNCH SETTING ADDITIONALLY?

OK CANCEL

prev Next

OK CANCEL EXIT

NewSimpleCopy SIMPLE COPY (DOUBLE SIDED SUPPORTED) 3.32 0

**FIG. 79**

The screenshot displays a software interface with a menu bar and a toolbar. A dialog box is open in the center, titled "FOLLOWING EXTENSIONS CAN BE ADDED TO SELECTED APPLICATION". The dialog contains a table with two rows: "StampTool" with version "1.10" and "TextTool" with version "1.20". Below the table is an "OK" button. The background interface includes a menu bar with "K" and a toolbar with icons for "print", "scan", and "copy2". The main window has a menu bar with "FILE COPY", "INSTALL", "SWITCH KEY SETTING", "LAUNCH SETTING", "UNINSTALL", and "SET". The status bar shows "NewSimpleCopy" and "SIMPLE COPY (DOUBLE SIDED SUPPORTED)".

Extension Name	Version
StampTool	1.10
TextTool	1.20

FIG.80




FIG.81

FILE COPY		INSTALL		SWITCH KEY SETTING		LAUNCH SETTING		UNINSTALL		SET		
K	print	scan		scan	<p>FOR USING THE SELECTED APPLICATION          "SIMPLE SCANNER" NEWER THAN VER 2.0          PRODUCED BY x x x SOFT DEVELOPMENT COMPANY IS NECESSARY.          &lt;CONTACT&gt;          x x x SOFT DEVELOPMENT COMPANY          ADDRESS: T XXX-xxxx          TEL: XXX-XXX-XXXX</p>							
copy2	NewSimpleCopy	SIMPLE COPY (DOUBLE SIDED SUPPORTED)				3 32	0	Next	prev	OK	CANCEL	EXIT